



# K-RZC2

---

VAL / SKC

TDC SENSOR CABLE FOR RGP42CD

ROTOR, INNER PART

DESCRIPTION

## CONTENTS


1. GENERAL
2. CONNECTION DRAWING
3. MOUNTING INSTRUCTION
4. OUTLINE DRAWING



## 1. GENERAL

The cable K-RZC2 is used as the inner cable in the rotor when the CD-holder is used in the RGP-42CD/DD refiner. It is connected between the outer rotor cable (K-RZC2) and the shaft centre cable (K-RZD2).

## 2. CONNECTION DRAWING



## 3. MOUNTING INSTRUCTION

- Mount one side to the cable K-RZD2 at the centre of the shaft.  
Mount also the centering device to unload the connector from radial forces.
- Mount the other end to the cable K-RZC1 in the segment holder.

## 4. OUTLINE DRAWING

